



How to Set Leaf Spring 26 in Place in Assembling Chuck



If Chuck is assembled in the wrong way in repairing - with the hole side of Leaf Spring 26 facing the Motor Housing side, the function of "Easy bit change by merely turning chuck" might be lost due to the interference between the end face of Compression Spring 35 and that of Leaf Spring 26.