

T ECHNICAL INFORMATION



Y06152

June 2012
(Page 1 of 8)

Subject ► Change of Parts numbers

For Models ► All models using the following parts

Country ► All countries using the following parts

Description ► Parts numbers have been changed for standardization. The actual parts remain the same.

Note: 1. Some parts descriptions have been changed.

2. **Y06152** is issued as unification of the following documents for Makita/ Dolmar internal use.
94751, 95101, 95234, 95269, 95300, 95301, 95326, 95330, 95426, 95510, 95570, 95577,
95588, 95592, 95593, 95594, 95595, 95596, 95597, 95598, 95600, 95604, 95610, 95662,
95711, 96103, 96204, 96233, 96285, 96327, 96344, 96484, 96494, 96559, 96687, 96740,
96776

Current	New	New description
0011306140	266662-6	Hex. bolt M6x14
0011306180	266663-4	Hex. bolt M6x18
0011306320	266664-2	Hex. bolt M6x32
0011406120	266674-9	Hex. bolt M6x12
0011806160	266641-4	Hex. bolt M6x16
0011806283	266639-1	Hex. bolt M6x28
0016605080	266676-5	Hex. bolt M5x8
0016706500	266666-8	Hex. bolt M6x50
0017006080	266611-3	Hex bolt M6x8
0021705000	264086-0	Hex. nut M5
0021805000	264035-7	Hex. nut M5
0021806003	264048-8	Hex. nut M6
0023710000	264054-3	Flange nut M10
0031005000	267446-5	Washer 5
0031205003	267394-8	Flat washer 5
0031424000	257987-9	Retaining ring (INT) R-24
0031426000	257988-7	Retaining ring (INT) R-26
0031455000	257966-7	Retaining ring (INT) 55
0031515000	257967-5	Retaining ring (EXT) 15
0031532000	257989-5	Retaining ring (EXT) S-32
0037006000	346305-7	Gasket
0043105600	266695-1	Pan head screw M5x60
0043406350	266667-6	Pan head screw M6x35
0043504080	266645-6	Pan head screw M4x8
0043505100	266646-4	Pan head screw M5x10
0043505123	266647-2	Pan head screw M5x12
0043505300	266708-8	Pan head screw M5x30 with SW
0043505303	266709-6	Pan head screw M5x30 with SW
0043604253	266807-6	Pan head screw M4x25 with WR
0043605160	266494-1	+ Pan head screw M5x16
0043605580	266594-7	Pan head screw M5x58 with WR
0100069760	266710-1	+ Hex. bolt M6x45
0100069790	266575-1	Hex. head bolt M6x30
0105064970	266696-9	Stud bolt M6x30
0119049930	266602-4	Hex. socket head bolt M4x20
0119049960	266810-7	H. S. H. bolt M4x10
0119059470	266812-3	H. S. H. bolt M5x16
0119059510	266811-5	H. S. H. bolt M5x14
0119059520	266440-4	Hex. socket head bolt M5x40
0119059531	266813-1	H. S. H. bolt M5x16 with WR
0119059550	266754-1	Socket head bolt
0119059570	266789-2	H. S. H. bolt M5x30 with WR
0119059600	266697-7	Socket head bolt M5x45

Current	New	New description
0119059631	266590-5	Hex.S.Head bolt M5x20 with WR
0119059640	266793-1	Hex. S. H. B. M5x25 with WR
0119059661	266592-1	Hex. socket head bolt M5x50
0119059720	266698-5	Hex. socket head bolt M5x20
0119059730	266814-9	Hex socket head bolt M5x20
0119059810	266794-9	Hex socket head bolt M5x50
0119059850	266711-9	Hex socket head bolt M5x14
0119059860	266573-5	Hex socket head bolt M5x33
0119059870	266787-6	H. S. H. bolt M5x18 with WR
0119059880	266712-7	Hex socket head bolt M5x25
0119059890	266805-0	H. S. H. Bolt M5x25 with W
0119069630	266648-0	Socket head bolt M6x20
0119069680	266649-8	Socket head bolt M6x30
0119069710	266661-8	Hex socket head bolt M6x18
0119069740	266638-3	Hex socket head bolt M6x30
0119069780	266589-0	Hex socket head bolt M6x60
0119069880	266680-4	Hex socket head bolt M6x20
0119069910	266668-4	Hex socket head bolt M6x18
0130059980	266595-5	Hex. head bolt M5x14
0130069940	265577-4	Hex head bolt M6x16
0130069970	266596-3	Hex. head bolt M6x16 with W
0140059340	266677-3	Pan head screw M5x14
0140059350	266699-3	Pan head screw M5x18
0140059370	266808-4	P. H. Screw M5x12 with WR
0140059390	265195-8	+ Pan head screw M5x12
0140059480	266809-2	P. H. Screw M5x14 with WR
0140059500	266700-4	Pan head screw M5x25
0140059520	266701-2	Pan head screw M5x25
0140059630	266591-3	Pan head screw M5x14
0140059680	266678-1	Pan head screw M5x25
0140059921	266572-7	+ Truss head screw M5x8
0140069890	266679-9	Pan head screw M6x16
0149069961	325663-4	Adjust screw
0149069972	325934-9	Adjust screw
0150049890	266748-6	Tapping screw 4x12
0150059760	265878-0	Tapping screw BT 5x16
0150059780	266713-5	Tapping screw 5x20
0150059790	266702-0	Tapping screw 5x14
0150059830	266714-3	Tapping screw 5x16
0200069920	267427-9	Flat washer 7
0200089781	267428-7	Flat washer 8
0200089800	267424-5	Flat washer 8
0200089911	267817-6	Washer 8

Current	New	New description
0200109870	267832-0	Wave washer 10
0213069990	423376-2	Gasket
0213169990	424100-6	Gasket
0213229990	424343-0	Gasket
0230049940	331835-1	Spacer
0230059880	346394-2	Spacer
0230059900	331948-8	Spacer
0230059970	257779-6	Spacer
0230059990	346438-8	Spacer
0240139950	213591-4	O ring 14
0240139970	213539-6	O ring 14
0240159990	213540-1	O ring 15
0240209990	213548-5	O-ring 20
0323039990	254040-2	Woodruff key 3
0440109970	213148-1	Oil seal 10
0440109980	213638-4	Oil seal
0440129940	213682-1	Oil seal 12
0440129950	213537-0	Oil seal 12
0440129960	213147-3	Oil seal 12
0440129970	213628-7	Oil seal
0440159971	213546-9	Oil seal 15
0440179910	213599-8	Oil seal (S)
0440209890	213598-0	Oil seal (L)
0561059970	282020-8	Hose clamp
0561059990	345920-4	Hose clamp
0561079990	346454-0	Hose clamp
0561080010	345918-1	Hose clamp
0561139982	346285-7	Hose clamp
0563749980	687686-3	Wire band
0565089970	233976-8	Clip
0565099990	233983-1	Clip
0565119990	233995-4	Ring spring 12
0566059980	345963-6	Clamp
0600069990	210083-4	Ball bearing 626ZZ
0600079990	210127-0	Ball bearing 627ZZ
0600109910	210082-6	Ball bearing 6000DDU
0600109940	210120-4	Ball bearing 6000ZZ
0600109980	210086-8	Ball bearing 6000
0600129790	211369-9	Ball bearing 6201
0600129810	210111-5	Ball bearing 6201LLU
0600129820	210122-0	Ball bearing 6001ZZ
0600129850	210113-1	Ball bearing 6001
0600129970	210128-8	Ball bearing 6201
0600129980	210129-6	Ball bearing 6001ZZ
0600159810	210204-8	Ball bearing 6202DDU
0600159820	211248-1	Ball bearing 6002DDU
0600159880	210202-2	Ball bearing 6202
0600179800	210123-8	Ball bearing 6003DDU
0610089970	212702-8	Needle cage 810
0630029730	168518-8	Control cable
0630089850	168470-0	Control cable
0641279990	168585-3	Fuel filter
0650109930	168534-0	Spark plug
0650109950	168401-9	Spark plug
0650149661	168648-5	Spark plug (BPMR7A)
0650149710	168588-7	Spark plug

Current	New	New description
0650149721	168662-1	Spark plug (BMR7A)
0650149810	168663-9	Spark plug (BM7A)
0654009931	324891-8	Plug cap spring
0655009870	424337-5	Plug cap
0662009870	650680-8	Switch
0717049990	783223-2	Wrench 4
0717059990	783232-1	Hex. wrench 5
0722105000	242072-1	Oil bottle
0736259880	892911-1	Indication label
0736369940	800F62-2	Caution label
0739159990	808721-6	Label
0851069920	412102-4	Tube
0851089950	444021-6	Tube
0851159850	162329-3	Tube
0851159861	412119-7	Tube guard 20-160
0851179961	162328-5	Tube
0851189950	158911-4	Tube complete
0851219950	168794-4	Tube complete
0851279970	168765-1	Tube complete
0851289960	168766-9	Tube complete
5013502400	346489-1	Air cleaner plate
5016004010	352010-6	Inlet screen
5016004130	442183-4	Metering diaphragm gasket
5025001020	232257-7	Spiral spring
5036500200	424102-2	Plate
5036500300	424103-0	Plate
5103502801	442177-9	Gasket air cleaner
5106013001	125799-7	Fuel tank cap assembly
5191500301	442173-7	Cylinder gasket
5191500400	442174-5	Crank case gasket
5191500901	318785-7	Cylinder
5192001003	141047-6	Crank shaft complete
5192500500	268277-5	Piston pin
5193001002	168679-4	Exhaust muffler
5193017030	443168-3	Air cleaner plate element
5193017040	213632-6	O-ring 14.8
5193018010	126036-2	Air cleaner plate assembly
5193018020	452971-1	Air cleaner case
5193500002	168680-9	Muffler gasket
5193500101	452988-4	Muffler plate
5193500501	442175-3	Insulator gasket
5195002060	266585-8	Tapping screw 5x12
5195002100	325923-4	Swing arm
5195002110	451938-6	Collar
5195009000	126037-0	Recoil starter assembly
5195019020	451940-9	Cam plate
5195019030	233984-9	Damper spring
5195500000	168483-1	Pulley
5195503000	452973-7	Cylinder cover
5195503100	452974-5	Cylinder cover
5196002020	325924-2	Jet
5196009010	325985-2	Jet
5196036000	168681-7	Carburetor
5196043000	168682-5	Carburetor
5196500003	452989-2	Fuel tank
5196500302	424104-8	Damper

Current	New	New description
5197011010	168683-3	Ignition coil
5197017010	318791-2	Flywheel
5197018000	141049-2	Wire complete
5197500100	424445-2	Plug cap cover
5206008030	266581-6	Pan head screw M3x8 with W
5206008110	424439-7	Plug
5212500500	257320-5	Piston ring
5215002030	232258-5	Spiral spring
5215002110	424317-1	Starter knob
5216002020	266770-3	Screw
5216006040	267461-9	Washer
5216006050	213684-7	O ring
5216008010	266795-7	Adjust screw
5216500200	424446-0	Damper
5219002000	195144-0	Stand set
5225004020	424319-7	Starter knob
5231501804	318762-9	Cylinder
5231502202	424447-8	Crank case gasket
5231502304	442171-1	Cylinder gasket
5232502600	257781-9	Piston pin
5233013020	453982-9	Air cleaner cover
5233013030	332044-5	Sleeve
5233013040	346626-7	Plate
5233014000	141056-5	Insulator complete
5233503902	424448-6	Insulator gasket
5233504700	443167-5	Air cleaner element
5233505201	346490-6	Insulator carburetor
5235025001	168664-7	Pulley
5235504700	266703-8	Hex. head bolt M6x14
5236018020	424444-4	Packing ring
5236018040	325922-6	Swivel
5236046010	266582-4	Tapping screw 3x24
5236046040	442154-1	Metering diaphragm gasket
5236046050	346270-0	Primer pump cover
5236046060	140988-3	Air purge body assembly
5236046130	140989-1	Pump body assembly
5236046140	140438-8	Air purge body
5236052020	346491-4	Bracket cable
5236503900	163447-0	Gasoline filter
5237034014	318765-3	Flywheel
5237046000	638707-4	Lead unit
5237503202	424449-4	Grommet
5242500701	257979-8	Piston ring
5245001010	266670-7	Pan head screw M5x18
5245001050	444036-3	Starter rope
5246001010	213538-8	O ring 2
5246001030	442172-9	Pump gasket
5246001040	168575-6	Pump diaphragm
5246001150	424314-7	Primer pump
5246001240	266704-6	Pan head screw M3x10
5252016001	140990-6	Crankshaft complete
5252500800	318766-1	Piston

Current	New	New description
5253021000	140993-0	Cleaner plate complete
5253033010	352016-4	Spark arrester
5253073000	168665-5	Exhaust muffler
5253500300	424450-9	Spacer gasket
5253501300	453410-4	Cleaner plate complete
5253502600	452917-7	Air cleaner case
5253503100	168666-3	Muffler gasket
5255001040	424359-5	Damper
5255011000	126010-0	Recoil starter assembly
5255016020	444024-0	Starter rope
5255040030	232262-4	Spiral spring
5255050010	451939-4	Reel
5255503300	452918-5	Cylinder cover
5255505200	452919-3	Cylinder cover
5256013010	326086-9	Jet
5256022020	126230-6	Throttle valve assembly
5256058000	452920-8	Fuel tank cap
5256059000	168668-9	Fuel tank cap complete
5256065010	326027-5	Jet
5256067000	140436-2	Strap complete
5256086000	168669-7	Carburetor
5256501801	452921-6	Fuel tank
5257018001	638665-4	Lead unit
5257027011	168671-0	Coil
5257500300	424313-9	Grommet
5259500300	286284-6	Cap
5265007050	233578-0	Damper spring
5266009010	168620-7	Metering diaphragm
5266500100	163518-3	Gasoline filter
5267007000	141700-4	Wire complete
5267500000	452049-0	Spacer
5268500000	168498-8	Clutch shoe
5268500100	231858-8	Tension spring 6
5305002110	140884-5	Starter knob complete
5306002240	265793-8	Wing bolt M5x5
5306002410	213590-6	O ring
5306008010	318667-3	Float body
5306009020	452280-8	Float
5306009120	346348-9	Spring plate
5306009150	163519-1	Needle
5306009160	268270-9	Stright pin
5306009210	442163-0	Gasket
5306009220	442162-2	Gasket
5306009230	346350-2	Float arm
5306009240	234199-1	Spring
5306009250	286291-9	Cap
5306009260	286035-7	Mixing cap
5306009310	325997-5	Adjuster cable
5306009450	259049-9	E-ring
5306009460	264045-4	Nut
5306009510	266633-3	Pan head screw M4x16
5306018020	325999-1	Main jet

Current	New	New description
5309010000	452192-5	Fuel mixture
5313003030	346627-5	Choke valve
5313003050	424523-8	Washer
5313003110	453983-7	Cleaner cover clip
5315001020	424361-8	Starter knob
5315001030	424360-0	Rope stopper
5315022020	451923-9	Reel
5315022040	444018-5	Starter rope
5315023000	165606-2	Pulley
5316005030	346608-9	Metering diaphragm cover
5316005120	257964-1	Stop ring E-3
5316005250	168767-7	Metering diaphragm
5316005450	264065-8	Cable adjust nut M6
5316020020	326084-3	Cable adjust screw M6x13
5316500701	424315-5	Check valve
5316503300	168396-6	Breather
5318003000	125757-3	Clutch assembly
5318003010	168563-3	Clutch shoe
5318003020	231863-5	Tension spring 9
5318500503	266571-9	Shoulder hex. bolt M8x23
5323006000	168649-3	Exhaust muffler
5323012000	126212-8	Air cleaner assembly
5323500600	168584-5	Muffler gasket
5402500600	257309-3	Piston ring
5403500600	442189-2	Insulator gasket
5411500300	318630-6	Cylinder
5411500501	442156-7	Cylinder gasket
5411501200	442157-5	Crankcase gasket
5412001000	125795-5	Crankshaft assembly
5412501300	212085-6	Needle cage 1014
5412505200	257797-4	Piston pin
5413006000	126211-0	Lead valve assembly
5413007000	125796-3	Lead valve assembly
5413044010	453981-1	Air cleaner housing
5413044020	443180-3	Air filter
5413500100	452762-0	Muffler cover
5413500401	452763-8	Air cleaner case
5413500500	452764-6	Air cleaner cover
5413500600	443161-7	Element
5413501100	451999-6	Insulator assembly
5413501200	442158-3	Insulator gasket
5413502700	443164-1	Air cleaner element
5413502800	442160-6	Lead valve gasket
5413503200	346541-5	Muffler cover
5413504300	346439-6	Muffler bracket
5413507700	443162-5	Air cleaner element
5413508900	452001-8	Air cleaner cover
5413509101	453971-4	Insulator
5413509200	452000-0	Air cleaner plate
5413509300	451998-8	Muffler cover
5413509600	442190-7	Carburetor gasket
5415001000	125935-5	Starter rewind

Current	New	New description
5415001010	452766-2	Reel
5415001020	452767-0	Ratchet
5415001030	233993-8	Spiral spring
5415001040	452768-8	Ratchet guide
5415001050	233994-6	Friction spring
5415001060	267443-1	Washer 5
5415001140	444030-5	Starter rope
5415001160	264083-6	Nut
5415001220	267444-9	Thrust washer 10
5415060000	125798-9	Recoil starter assembly
5415060020	452288-2	Reel
5415060040	266634-1	Set screw M6x20
5415503000	424413-5	Starter cap
5415506900	452769-6	Cylinder cover
5415507200	452002-6	Blower housing
5415507500	452003-4	Cylinder cover
5416001010	286290-1	Cap
5416001020	140633-0	Cock body complete
5416001030	331923-4	Cable guide
5416001040	452279-3	Packing
5416001060	266632-5	Adjust screw
5416001110	234198-3	Spring
5416001130	352011-4	Filter
5416008021	318666-5	Piston valve
5416016030	346349-7	Plate
5416016040	422069-8	Hose
5416019001	168590-0	Carburetor
5416019010	325998-3	Jet needle
5416040000	168651-6	Carburetor
5416041001	168764-3	Carburetor
5416041010	453970-6	Throttle valve
5416041020	326211-2	High speed needle
5416061000	168586-1	Fuel tank bracket assembly
5416500000	452770-1	Fuel tank
5416500200	422060-6	Fuel tube
5416501300	442159-1	Carburetor gasket
5416504401	452004-2	Fuel tank
5416504801	453969-1	Fuel tank
5416505600	424336-7	Fuel tank bumper
5416505700	424335-9	Bracket bumper
5417023010	318739-4	Flywheel magnet
5417023030	140885-3	Wire complete
5417037001	125936-3	Cap cover assembly
5417041010	318632-2	Flywheel
5417041020	168587-9	Ignition coil
5417500100	326162-9	Earth spring
5417500300	422059-1	Tube
5418001000	125829-4	Clutch assembly
5418002010	168622-3	Clutch shoe
5418002020	231869-3	Spring
5418500500	266597-1	Shoulder hex. bolt M8
5418500601	313197-9	Holder

Current	New	New description
5421500500	267400-9	Flat washer 23
5423006000	140995-6	Insulator complete
5423500902	452922-4	Insulator
5425003010	266580-8	Tapping screw 5x10
5426005030	413140-9	Washer
5516500501	423412-4	Gasket
5806080110	234262-0	Compression spring
5921004001	140023-7	Rocker cover complete
5921500400	325665-0	Joint pipe
5921500502	318443-5	Cam gear cover
5921500700	162274-2	Cam gear cover gasket
5921500800	162275-0	Rocker cover gasket
5921500900	422041-0	Breather pipe
5921501000	346083-9	Lead valve
5921501100	318440-1	Retainer plate
5921501400	424200-2	Spacer
5921501800	424201-0	Check valve
5923008011	324980-9	Spark arrester
5923016000	450559-1	Insulator
5923018000	125916-9	Insulator assembly
5923500501	268238-5	Pin 5
5923500600	268239-3	Pin 4
5923500700	256865-0	Rod 2.5
5923501200	234108-0	Compression spring 9
5923501300	325668-4	Spring retainer
5923501900	413138-6	Carburetor gasket
5923502200	451925-5	Choke lever
5923502301	450560-6	Choke plate
5923502500	451924-7	Check valve plate
5923502600	345919-9	Plate
5923503001	422042-8	Pipe
5923503100	265188-5	+Pan head screw M5x68
5923503400	345915-7	Muffler cover
5923503500	168577-2	Separator gasket
5923504000	413121-3	Carburetor gasket
5923504300	168593-4	Muffler gasket
5923504600	324961-3	Intake pipe
5923504700	413120-5	Insulator gasket
5925001002	125917-7	Starter cover assembly
5925001030	451937-8	Reel
5925001050	444019-3	Starter rope
5925022000	168471-8	Pulley
5926002020	234183-6	Conical compression spring 5-9
5926002040	442155-9	Pump gasket
5926002140	140437-0	Pump body
5926003000	168472-6	Tube complete
5926008010	168574-8	Metering diaphragm
5926009000	168497-0	Carburetor
5926016000	140435-4	Fuel tank cap
5926017000	125472-9	Fuel tank cap assembly
5926021000	140813-8	Oil pipe complete
5926022001	168641-9	Carburetor

Current	New	New description
5926023000	452048-2	Oil pipe
5926031000	168550-2	Carburetor
5926500000	318442-7	Oil case
5926500100	162276-8	Case gasket
5926500200	424202-8	Oil tube
5926500300	325666-8	Oil weight
5926500400	450566-4	Fuel tank
5926500600	450565-6	Oil gauge
5926500900	424530-1	Oil case guard
5926501300	450562-2	Clamp
5926501500	452047-4	Oil cap
5926501600	424181-0	Oil guard
5926501700	452610-3	Oil gauge
5926501800	318954-0	Oil case
5926501900	454185-8	Fuel tank
5926502000	162351-0	Case gasket
5926502100	424344-8	Damper
5926502400	451251-2	Fuel tank
5927001021	318343-9	Flywheel
5927003000	638664-6	Lead unit
5927005001	125474-5	Switch assembly
5927010000	638709-0	Lead unit
5927011000	638710-5	Lead unit
5927012011	168501-5	Ignition coil
5927017010	168790-2	Ignition coil
5927500000	450568-0	Plug cover
5927500100	424105-6	Plug cap
5927500200	318702-7	Flywheel
5928500300	267812-6	Washer 6
5929002000	196134-6	Tool set
5929500800	345964-4	Tank guard
5931004000	140419-2	Rocker cover complete
5931021000	125755-7	Cylinder block assembly
5931500800	162307-3	Rocker cover gasket
5931500900	422055-9	Breather pipe
5932500400	318613-6	Piston
5932500900	257796-6	Piston pin
5932501000	267425-3	Flat washer 26
5933001000	125468-0	Cleaner plate assembly
5933003000	125552-1	Cam gear assembly
5933005000	140814-6	Air cleaner plate complete
5933018000	451874-6	Insulator
5933500000	256866-8	Rod 2.5
5933500100	256200-2	Pin 5
5933500200	234181-0	Compression spring 13
5933500300	325912-9	Spring retainer
5933500700	452611-1	Air cleaner plate
5933500800	450561-4	Air cleaner cover
5933500900	443140-5	Air cleaner element
5933501200	443141-3	Air cleaner element
5933501600	168576-4	Separator plate
5933502100	422070-3	Pipe

Current	New	New description
5933504000	325915-3	Intake pipe
5935002000	195142-4	Recoil starter set
5935500200	318614-4	Blower housing
5935500500	451876-2	Plug cover
5935500802	451875-4	Cylinder cover
5935500902	451884-3	Cylinder cover
5936002010	325921-8	Jet
5936003000	162309-9	Tube
5936004000	168561-7	Carburetor
5936025010	140808-1	Pump body
5936500000	318612-8	Oil case
5936500100	162308-1	Case gasket
5936500200	451877-0	Fuel tank
5936502700	451978-4	Fuel tank
5937001021	318611-0	Flywheel
5938500000	266800-0	Shoulder hex. bolt M8x24
5971500502	442167-2	Cylinder head gasket
5971500600	318725-5	Cam gear cover
5971500800	442168-0	Cam gear cover gasket
5972500800	267448-1	Flat washer 41
5973502200	452952-5	Hose joint
6114007000	196062-5	Handle set
6119019001	195508-8	Accessory set
6161027000	126040-1	Flexible pipe assembly
6161501400	422086-8	Spacer
6161501500	331959-3	Spacer
6162005002	168672-8	Clutch
6162011000	141050-7	Clutch drum complete
6163005000	126041-9	Gear case assembly
6164010000	126042-7	Handle assembly
6164500700	273673-4	Grip
6165028001	126043-5	Controller assembly
6165029000	126044-3	Controller assembly
6165500201	638784-6	Wire
6168016002	126045-1	Protector assembly
6168020000	126048-5	Cutter assembly
6169030000	195600-0	Tool set
6169508100	892914-5	Dolmar logo label
6191006001	141058-1	Clutch case complete
6191500203	424461-4	Pipe damper
6191500401	324893-4	Shaft
6191501300	318792-0	Pipe bracket
6191501800	325812-3	Shaft
6191502100	443170-6	Felt
6192006000	126049-3	Clutch assembly
6193006120	257986-1	Retaining ring (EXT) S-9
6194500400	331908-0	Handle
6195006010	451931-0	Stay (R)
6195006020	451932-8	Stay (L)
6195006030	451933-6	Long lever
6195006050	233568-3	Torsion spring
6195006060	266584-0	Tapping screw 4x20

Current	New	New description
6195006150	451936-0	Top
6195013010	452278-5	Stop lever
6202500400	266746-0	Hex. head bolt M6x14
6202500600	267429-5	Flat washer 6
6211026000	140996-4	Shaft pipe complete
6211506200	324944-3	Boss
6213500500	213681-3	Oil seal 16
6214001000	273532-2	Grip
6214015000	273531-4	Grip
6214016000	125567-8	Handle assembly
6214017000	125568-6	Handle assembly
6214500400	273534-8	Grip 23
6214502400	332073-8	Handle
6214502600	331901-4	Handle
6214502700	273530-6	Grip
6215022030	452277-7	Long lever
6215022040	264049-6	U nut M5
6215023060	451934-4	Stop lever
6215029001	126013-4	Control lever assembly
6215030000	126014-2	Control lever assembly
6215031000	141077-7	Switch holder complete
6218003001	168481-5	Clamp washer complete
6218016000	122976-2	Cutter assembly
6218020001	122977-0	Cutter assembly
6218500000	332042-9	Receive washer
6218500200	450653-9	Guard
6218501601	324917-6	Receive washer
6219110000	892916-1	Caution label
6219530200	800C50-1	Caution label
6241002002	141785-0	Shaft pipe complete
6241500501	424107-2	Pipe damper 2
6241500701	318271-8	Pipe bracket 2
6241501500	318270-0	Pipe bracket 1
6242003000	168475-0	Clutch drum
6242500100	346000-9	Flat washer 23
6243006002	125476-1	Gear case assembly
6243500600	318292-0	Gear case
6247006000	125520-4	Band assembly
6247500200	422045-2	Cushion
6248003001	453903-1	Cup
6249000000	196194-8	Tool set
6251043003	141244-4	Clutch case complete
6251047003	140997-2	Clutch case complete
6251506604	424451-7	Pipe damper 1
6251506703	424452-5	Pipe damper 2
6251509501	318767-9	Pipe bracket 1
6251509600	318768-7	Pipe bracket 2
6251510500	326205-7	Shaft
6252014003	168675-2	Clutch drum complete
6252021000	168494-6	Clutch drum
6252024000	168609-5	Clutch drum
6252500400	266457-7	Shoulder hex. bolt M6x25

Current	New	New description
6253011012	265578-2	+Hex. bolt M6x8
6253030000	126205-5	Gear case assmbly
6254019010	452923-2	Hanger
6254019020	452924-0	Hanger stopper
6254021002	451914-0	Band complete
6254503802	318272-6	Handle holder
6255008000	125477-9	Control lever
6255016001	125937-1	Fuel tank cap assembly
6255018030	266723-2	Pan head screw M5x20
6255021002	452771-9	Strap unit
6257500100	168676-0	Cushion
6258053001	140424-9	Protector complete
6258505001	264018-7	Hex. nut M8
6258505901	345923-8	Protector clamp
6258507600	729022-8	Cutter blade
6258508200	346493-0	Protector clamp
6258509300	346622-5	Guard
6259514700	808723-2	Caution label
6271023000	168495-4	Damper
6271501501	450659-7	Spacer
6271502800	326208-1	Boss
6274500100	331941-2	Handle
6274500801	331909-8	Handle 19
6274500901	331821-2	Handle
6274501000	273526-7	Grip 18
6274501101	331910-3	Handle 19
6274501200	331951-9	Handle
6278013000	122978-8	Cutter assembly
6278501501	729065-0	Cutter
6301001000	140629-1	Stopper complete
6301501500	257974-8	Retaining ring (EXT) 28
6301501600	267445-7	Washer 24.5
6305500500	346286-5	Stand
6308503100	346441-9	Clamp washer
6308503200	264058-5	Nut M10
6308503300	264062-4	Nut M10
6341001001	140042-3	Shaft pipe complete
6341003000	140878-0	Shaft complete
6341004000	141335-1	Shaft pipe complete
6341006000	140819-6	Shaft pipe complete
6341500201	318421-5	Clutch case
6341500300	318453-2	Pipe retainer
6341500400	318454-0	Pipe bracket
6341500500	424204-4	Damper
6341500600	451157-4	Spacer
6341501100	443146-3	Felt ring 8
6341501600	318713-2	Clutch case
6341501900	318699-0	Bracket pipe
6341502100	326033-0	Shaft
6341502200	452638-1	Spacer
6341502300	424400-4	Damper pipe
6341502400	452639-9	Wire clamp

Current	New	New description
6341502500	452640-4	Wire clamp
6342002000	140846-3	Clutch drum complete
6342005001	140820-1	Clutch drum complete
6343004001	126272-0	Gear case assembly
6343004030	264025-0	Hex. nut M10-17
6343006000	125922-4	Gear case assembly
6344500600	452642-0	Handle
6344500700	273669-5	Grip
6344500800	273670-0	Grip
6345001000	162310-4	Tank guard
6345010000	353019-1	Control cable
6345011000	125925-8	Control lever assembly
6345500000	422071-1	Cable tube
6347001000	125558-9	Hanger assembly
6347003001	125938-9	Band assembly
6348003000	122931-4	Nylon head
6348500100	346404-5	Clamp washer
6348500300	346405-3	Protector clamp
6349007000	194904-7	Tool set
6349506200	816447-6	EBH340U Model No. label
6351006001	140628-3	Clutch case complete
6351500700	451160-5	Wire clamp
6351501000	257289-3	Spacer
6353500000	318731-0	Gear case
6355004010	125841-4	Wire assembly
6355004020	168621-5	Control cable
6357500000	168613-4	Cushion
6401032002	125940-2	Stopper assembly
6401032010	326119-0	Spacer
6401032020	264059-3	Wing nut
6401503002	318732-8	Stopper
6404502400	273671-8	Grip
6407006001	125941-0	Hanger assembly
6408501801	721471-5	Cutter blade 255
6411001000	140887-9	Shaft pipe complete
6411002000	140627-5	Shaft pipe complete
6411008000	424403-8	Damper
6411009002	140890-0	Shaft complete
6411010000	140891-8	Shaft pipe complete
6411011002	140892-6	Shaft complete
6411502101	413154-8	Stopper
6411502200	452287-4	Stopper
6412006001	140893-4	Clutch drum complete
6413500400	213596-4	Oil seal 18
6413500600	266671-5	Hex. socket head bolt M10x9
6414500100	318735-2	Handle holder 1
6414500600	331971-3	Handle
6415011001	125942-8	Control lever assembly
6415011030	452773-5	Lever
6415011040	452774-3	Lever
6415011050	452775-1	Stopper
6415011060	452776-9	Bracket

Current	New	New description
6415011110	233585-3	Spring
6415011120	233586-1	Spring
6415011140	264060-8	Nut M6
6415011150	266672-3	Pan head screw M5x35
6415011210	266673-1	Tapping screw 4x18
6415011221	125943-6	Wire assembly
6415011231	140896-8	Wire complete
6415017040	168768-5	Control cable
6415500000	346443-5	Stand
6417500200	346356-0	Hanger
6418017000	122979-6	Cutter assembly
6418026000	122932-2	Protector assembly
6418026010	346351-0	Protector clamp
6418500101	326053-4	Receive washer
6418500200	412099-7	Guard
6418500303	346263-7	Protector clamp
6418500701	450573-7	Tool cover
6418501400	729023-6	Cutter blade
6418501700	346444-3	Protector clamp
6419038001	195162-8	Accessory set
6419504300	898454-1	Choke label
6452002000	140897-6	Clutch
6458008001	122882-1	Cutter assembly
6601503001	233536-6	Torsion spring 5
6601503100	268230-1	Rod 4
6601503201	265782-3	Thumb screw M4
6601503400	257958-6	Retaining ring S-3.5
6601503500	424180-2	Gasket
6609045003	168791-0	Vacuum pipe complete
6609051000	166114-6	Dust bag
6609502802	453720-9	Elbow
6609503602	454187-4	Vacuum pipe 1
6609503701	454188-2	Vacuum pipe 2
6609503801	454241-4	Vacuum pipe 3
6609504800	800L75-9	Indication label
6609508500	140352-8	Hose clamp
6651002000	451755-4	Fan housing
6651003000	240113-7	Fan 180
6651006000	125730-3	Volute case L assembly
6651010000	125533-5	Volute case L assembly
6651014000	450958-7	Volute case R
6651500500	424182-8	Friction rubber
6655500000	273665-3	Grip
6656500100	450964-2	Plug cover
6659031000	125729-8	Nozzle assembly
6659042000	166115-4	Dust bag
6659500901	451752-0	Nozzle
6659501000	450966-8	Nozzle end
6659501100	451753-8	Nozzle end
6659504000	450965-0	Nozzle
6659504100	346602-1	Bracket
6676500805	453712-8	Engine cover

[illegible]