


- Subject** ▶ Change of Ball Bearing
- For Models** ▶ HM1200, HM1200B, HM1200K, HM1201, HM1211, HM1211B, HR3800, HR3811, HR3850, HR3850B, HR3850K, HR3851, HR5000 & HR5000K (Demolition Hammer & Rotary Hammer)
- Description** ▶ As illustrated below, Ball Bearing has been changed, for improvement in endurance.



Interchangeability(I/C)

Item No.	Current part		Q'ty	I/C	New part		Q'ty	Note
72	Ball Bearing 6200LLB 211066-7		1	<=	Ball Bearing 6200DDW 211087-9		1	

Note

Interchangeability mark <= means the new part is substituted for the current part.

Implementation

- HM1200: From Serial No. 42133E (April, 1998)
- HM1200B: From Serial No. 10364E (April, 1998)
- HM1200K: From Serial No. 53756E (April, 1998)
- HM1201: From Serial No. 74172E (April, 1998)
- HM1211B: From Serial No. 9712E (April, 1998)
- HR3811: From Serial No. 13507E (June, 1998)
- HR3850: From Serial No. 73802E (April, 1998)
- HR3850B: From Serial No. 42039E (April, 1998)
- HR3850K: From Serial No. 25580E (April, 1998)
- HR3851: From Serial No. 36208E (April, 1998)
- HR5000: From Serial No. 45419E (April, 1998)
- HR5000K: From Serial No. 50077E (April, 1998)