

- Subject** ▶ Modification of Housing Set and Set Plate,  
Addition of Wrench Holder 3.4
- For Models** ▶ 6831D
- Country** ▶ All countries
- Description** ▶ Housing set and Set plate has been modified.  
Wrench holder 3.4 has been added.  
See illustrations for the details.

▶ Current	▶ New
<p>Housing set (182658-8) with Wrench holder</p> <p>Set plate (344121-1) 14.0mm (9/16")</p> <p>This Housing set does not allow you to use push button type battery.</p>	<p>Housing set (183169-6) without Wrench holder</p> <p>Wrench holder 3.4 (Part No. 410048-8) is installed as a standard equipment.</p> <p>Set plate (343579-1) 10.5mm (13/32")</p> <p>The claws on housing set allow you to use push button type battery.</p> <div> <p>How to install Wrench holder 3.4 into the new Housing set</p> <p>Put the tail of Wrench holder 3.4 through the slit on the foot of Housing set.</p> <p>Bend Wrench holder 3.4 and put the tail of Wrench holder 3.4 through the slot to fix it with Housing set.</p> </div>

## Interchangeability(I/C)

Item No.	Current part		Q'ty	I/C	New part		Q'ty	Note
002, 048	Housing Set 182658-8		1	No	Housing Set 183169-6		1	Interchangeable as a set
006	Set Plate 344121-1		1	No	Set Plate 343579-1		1	
A06					Wrench Holder 3.4 410048-8		1	

## Implementation

As soon as the current parts run out of stock